

Cross Reference – Socket to Relay



Military Socket P/N	Military Relay Part Number	PCD Socket Number	Type
M12883/40-01 M12883/40-05 M12883/40-07 M12883/40-11 M12883/40-13 M12883/40-17 M12883/40-19 M12883/40-23	M83536/15-022 M83536/16-006, -014, -031, -034 M83726/1, /2, /3, /4, /28, /29, /30, /31* MS27709-2	RSL116079 RSL116087 RSL116051 RSL116059 RSE116661 RSE116669 RSE116673 RSE116681	4 Pole, 10 Amp
M12883/40-02 M12883/40-08 M12883/40-14 M12883/40-20	M883536/17-002, /17-005	RSL116081 RSL116053 RSE116663 RSE116675	4 Pole, 10 Amp
M12883/40-04 M12883/40-10 M12883/40-16 M12883/40-22	LEACH CORP. KA-D4E & J	RSL116085 RSL116057 RSE116667 RSE116679	4 Pole, 10 Amp
M12883/40-06 M12883/40-12 M12883/40-18 M12883/40-24	M83536/18-002, -005, -008, -012 M83536/19-002, -005, -008, -012 M83536/20-002	RSL116089 RSL116061 RSL116671 RSE116683	4 Pole, 10 Amp
M12883/41-01 M12883/41-04 M12883/41-06 M12883/41-09 M12883/41-11 M12883/41-14 M12883/41-16 M12883/41-19	M83536/9-006, -015, -024, -035 M83536/10-006, -015, -024, -034, -038	RSL116091 RSL116097 RSL116063 RSL116069 RSE116685 RSE116691 RSE116695 RSE116701	2 Pole, 10 Amp
M12883/41-02 M12883/41-07 M12883/41-12 M12883/41-17	M83536/11-002, -004, -007	RSL116093 RSL116065 RSL116687 RSE116697	2 Pole, 10 Amp
M12883/41-03 M12883/41-08 M12883/41-13 M12883/41-18	LEACH CORP. JA-D4E & J	RSL116095 RSL116067 RSE116689 RSE116699	2 Pole, 10 Amp
M12883/41-05 M12883/41-10 M12883/41-15 M12883/41-20	M83536/13-002, -005, -008, -012 M83536/14-002	RSL116099 RSL116071 RSE116693 RSE116703	2 Pole, 10 Amp
M12883/44-01	M83536/5-006, -014, -022, -030 M83536/6-006, -014, -022, -032	RSE120151	4 Pole, 5 Amp

Cross Reference – Socket to Relay (Cont.)

Military Socket P/N	Military Relay Part Number	PCD Socket Number	Type
M12883/44-02	M83536/7-022	RSE120153	4 Pole
M12883/45-01	M83536/1-006, -015, -024, -033 M83536/2-006, -015, -024, -035	RSE120159	2 Pole, 5 Amp
M12883/45-04	M6106/38-002	RSE120165	2 Pole, 5 Amp
M12883/46-01	M83536/21-006, -014, -022, -030 M83536/22-006, -014, -022, -031	RSE116747	3 Pole, 10 Amp
M12883/46-02	M6106/40-002	RSE116749	3 Pole, 5 Amp
M12883/47-01 M12883/47-04 M12883/47-07 M12883/47-10	M83536/25-002 M83536/26-002	RSE116755 RSE116761 RSL116101 RSL116073	6 Pole, 10 Amp
M12883/47-02 M12883/47-05 M12883/47-08 M12883/47-11	M83536/27-002	RSE116757 RSE116763 RSL116103 RSL116075	6 Pole, 10 Amp
M12883/48-01 M12883/48-02 M12883/48-03 M12883/48-04	M83536/32-003L M83536/33-003L	RSE112061 RSE112063 RSL112105 RSL112101	3 Pole, 25 Amp
M12883/52-001	M83536/2-028 M83726/24, /25*	RSE116175	2 Pole, 5 Amp Track Mount
M12883/52-002	M83536/6-025	RSE116185	4 Pole, 5 Amp Track Mount
M12883/52-003	M83536/22-025	RSE116195	3 Pole, 10 Amp Track Mount
M12883/54-01	M6106/13-002, 008, 011, 013, 015	RSE116627	3 Pole, 25 Amp
M12883/54-02	M6106/13-004	RSE116631	3 Pole, 25 Amp
M12883/54-03	M6106/12-002	RSE116629	3 Pole, 25 Amp
M12883/54-04	MS27742-2	RSE116635	3 Pole, 25 Amp
M12883/55-01 M12883/55-02	M6106/19-004, 007, 012, 017, 022	RSE112035 RSE112036	1 Pole, 25 Amp
M12883/55-03	M6106/20-002	RSE112044	1 Pole, 25 Amp

*Applies to all plug-in dash numbered relays of these documents

AEROSPACE AND DEFENCE AUSTRALIA

No.14/18 Blanck Street
Motorway Business Park
Ormeau QLD Australia 4208
Tel (07) 5549 0077
Fax (07) 5549 0088
www.aerodefence.com.au

